

## Battery Date Code

### Purpose

To determine the age of the batteries from 2006 to 2015 (orange and white batteries were released in 2016).

### Prerequisites

- Baby
- Battery cover key
- Phillips head screwdriver

### Steps to Perform

1. Remove battery cover



Remove the back cover by inserting the RealCare key into the keyhole, press down and turn 90 degrees counter-clockwise.

2. Remove screws



- Remove two screws and discard.
- Remove the module by pulling straight out.

3. Remove the battery pack from the tray and there should be a large sticker on the packaging.



Note the 049 circled in red on the battery below. This is monthyear format so the example of 049 is April of 2009.

4. The white stickers you see should have the date. Sometimes the batteries are turned around and need to be removed.



Cut the 2 zip ties on one of the batteries to turn it around. These are just standard zip ties if you need a replacement. If purchasing a Replacement Battery Kit, replacements will be included.

For additional assistance and video tutorials visit our website:

[www.realityworks.com/support/](http://www.realityworks.com/support/)